






Smart Toilet Instructions

Safety Note

Please read and follow the instructions carefully for installation. Save the instructions in proper place and do not lose it. In order to ensure the safety and avoid the loss, please follow the instructions as below.


Warning Show how to avoid the injury.

Caution Show what you should follow and not to do.

Sign	Note
	Forbidden
	Must Follow
WARNING	
	<ul style="list-style-type: none"> • Dismantle, repair or remold the product are forbidden or else you will get an electric shock or causes fire. • Drop the lighting cigarettes and burning objects into toilet bowl are forbidden or else you will causes fire. • Drop the water and detergent on the seat cover and plug are forbidden or else you will get an electric shock or causes fire. • Do not touch the plug with wet hands to avoid getting an electric shock. • The portable or tottering plug is forbidden or else you will get an electric shock or causes fire. • Do not replace the wire yourself while it is broken. The correct way is to call the professional maintenance staff to handle it.
	<ul style="list-style-type: none"> • Smart toilet belongs electric product. Do not use it in wet environment. • Make sure the voltage and plug can match the product or else it would be broken. • Drop the water and detergent on the seat cover and plug are forbidden or else you will get an electric shock or causes fire. • Do not touch the plug with wet hands to avoid getting an electric shock. • The portable or tottering plug is forbidden or else you will get an electric shock or causes fire. • Do not replace the wire yourself while it is broken. The correct way is to call the professional maintenance staff to handle it. • Make sure your ground lead wire can match the standard of law or else it is forbidden to use the product. • Ensure install the product with the pipe and fittings which is combined in the packing or else the toilet would be leaking. • Ensure the power and water valve is off while installing, dismantling and repairing. • Suggest clean out the water from product while room temperature below zero so as to avoid freezing. • People with disabilities or mental disabilities require use the product under supervision. • Require the cardiopath use the product with caution. • Do not allow children to play with the product.
	<ul style="list-style-type: none"> • Cut the power and pull out the plug during thunder. • Do not wipe the product with thinner, petrol, detergent and insecticide. • Adjust the seat temperature to be minimum while seat on toilet cover in a long time, or else the toilet would be leaking. • Do not turn the product upside down while the power is working but without water supply or else the heating device would be broken. • Make sure the input water is clean. Do not use the process water, waste water and seawater and re-collected water. • Do not place the product in direct sunlight or else the product would discolor and causes burns. • Do not lean your back to the cover while it is working or else the cover would be broken. • Do not press the cover strongly or else the soft down device would be broken.


List

Name of part




(ATTN: The photo is for reference only, refer only to the actual product)
(There could be minor difference between actual product and above graphic, due to production batches.)

Fittings



Side Button Instructions



Keep pressing the side STOP button to run or shut the toilet down.
The working function will stop by short pressing this button.



Press this button to start drying while there is people sitting on cover.
To end the function by pressing STOP button or leaving the cover.



Press this button to run bidet washing and press again to run moving washing while people seating on the cover.
To end the function by pressing STOP button or leaving the cover.




Press this button to run rear washing and press again to run moving washing while people seating on the cover.
To end the function by pressing STOP button or leaving the cover.



Press this button to flush once.
The flush can work only by pressing this side button while power off.

LED Display



(Display on the top of toilet)

37°C

Temp. of wash water

37°C

Temp. of seat cover



ECO indicator light
light-on
light-off

LED Display

Foot sensor flush

(This function is workable only for specific model)

Flush will run once time after the foot touching the sensor area without seating on cover.

Foot sensor open/close cover

(This function is workable only for specific model)

The cover will open/close itself after the foot touching the sensor area.

The cover will close itself in 1.5 mins without any operation after opening cover.

Microwave auto open cover

(This function is workable only for specific model)

The cover will open itself after people get close to the sensor area.


The cover will close itself in 1.5 mins without any operation after opening cover.

Smart Toilet Instructions

Remote control Instructions

Note: Please pair the code following the way below if the controller is not working at the first time in use.

- Press on side button both **STOP** and **BIDET** for 3-5 seconds. Press any button on controller when you hear a beep sound.
- Press any button on controller when you hear a beep sounds.
- The code will be paired when hear a beep sounds again.



Warning

PREVENT GETTING HURT IN BURNS

- Please do remember to shut down seat temp. and drying temp. so as to prevent getting hurt in burns in the situation as below:
 - ▲ The people who can not adjust the temperature as like as children, elder, etc..
 - ▲ The patients, disabled people or impaired physical mobility.
 - ▲ People who took the sleeping pills or over drinking or weary or drowsiness.

Remote for auto cover



The button "Temp. massage" will be changed to be button "Open cover" for auto cover remote.

Remark: The remote will not be the same for different models.



Remote open cover

(This function is workable only for specific model)

Press this button to open/close cover without seating on cover. The cover will close itself in 1.5 mins without any operation after opening cover.

Press this button to root auto function while there is people sitting on the seat cover bowl.
Includes 30s rear washing, 30s moving mode and 2mins drying. The working will stop itself or be ended by **Stop** button. This function is convenient to elders and children. Press this button after pressing **Bidet** button, the auto bidet washing will be rooted. The auto function will be off working while people left.

Rear

The nozzle will start rear washing by press this button while people sitting on the seat cover bowl.

The washing will finish in 1.5 minutes. It also can be stopped by **STOP** button.

While the rear washing is running, press this button can root the moving mode.

During the washing, you can adjust the strength of spray. The washing will stop itself after people leaving the seat.

Strong and weak massage

The water pressure will be adjusted from level 5 to level 1 rhythmically.

Reciprocating massage

The nozzle can move back and forth to clean more space.

Temperature massage

(This function is workable only for specific model)

The water temp. will be adjusted from hot level to normal rhythmically.

Water Temp.

Press this button to adjust water temperature in 4 levels.

Home temp. (Not heating)

Low temp. ($\approx 33^{\circ}\text{C}$).

Middle temp. ($\approx 36^{\circ}\text{C}$).

High temp. ($\approx 4^{\circ}\text{C}$).

Lighting

Press this button to turn on/off lighting.

Bidet

The nozzle will start bidet washing by press this button while there is people sitting on the seat cover bowl.

The washing will finish in 1.5 minutes. It also can be stopped by **STOP** button.

While the bidet washing is running, press this button can root the moving mode. During the washing, you can adjust the strength of spray.

The washing will stop itself after people leaving the seat.

Stop

The product will stop working by pressing this button while it is in use. The product will stop itself and auto flush once after people leaving the seat.

The auto flush will be rooted by pressing this button while no people sitting on the seat.

Nozzle forward

The position of nozzle can be adjusted forward in 5 levels while the washing function is working.

Water pressure +

Increase water pressure in 5 levels while washing.

Drying Temp.

Press this button to adjust drying temperature in 4 levels

Home temp. (Not heating)

Low temp. ($\approx 35^{\circ}\text{C}$).

Middle temp. ($\approx 45^{\circ}\text{C}$).

High temp. ($\approx 55^{\circ}\text{C}$).

ECO mode

Turn on/off energy safe mode by short pressing this button.

Drying

Press this button to start drying while there is people sitting on the seat cover bowl.

The drying will finish in 3 minutes. It also can be stopped by **STOP** button.

The drying temperature can be adjusted in 4 grades by temperature adjusting button.

The drying will stop itself after people leaving the seat.

Flush

Flush by short pressing this button.

Nozzle backward

The position of nozzle can be adjusted backward in 5 levels while the washing function is working.

Water pressure -

Reduce water pressure in 5 levels while washing.

Seat cover Temp.

Press this button to adjust seat cover temperature in 4 levels

Home temp. (Not heating)

Low temp. ($\approx 34^{\circ}\text{C}$).

Middle temp. ($\approx 37^{\circ}\text{C}$).

High temp. ($\approx 4^{\circ}\text{C}$).

Nozzle self-cleaning

Press this button to clean the nozzle for 15 seconds without seating on the cover.

Press this button again to stop.

Smart Toilet Instructions

Installation of smart toilet




The electric plug must follow the rule as below:

- The length of wire is 1.5m at least and the plug should be close to product for easy installation and dismantling.
- The plug and product should stay away from bathtub.
- Suggest to use the water proof plug and do not use the portable plug.
- Install and use the product in correct way or else you will get electric shock or causes fire.

Step of Installation

1. Drawing the cross center line on the output hole on the floor.




3. Put the toilet on the output hole on floor and aim the cross center line both on toilet and floor so as to test the toilet can match the roughing-in or not.



5. Put the toilet on the output hole on floor. The seal ring should be aimed to output hole and make sure those two cross center line coincide together. Press the toilet down slowly until the bottom of toilet match the horizontal line.




7. Apply mould proof sealant evenly between the bottom edge of toilet and ground. Plug in power and open the valve slowly after the sealant solidify. Adjust the water pressure to be 7.5KGS and check the tightness for each connection.



Installation of hose


1. Replace the new valve and connect the hose to it. The other side of hose connect to the filter.
2. Plug in power and adjust the water pressure to be less than 7.5KGS by valve.




Required tools




2. Put the toilet upside down on soft mat. Drawing the cross center line on the output hole and extend the line to the edge of toilet.



4. Put the toilet upside down on soft mat. Apply the glass glue evenly to inside of seal ring and outside of output hole on toilet. Make sure the seal ring is fixed on the output hole. (Do not forget to take off the packing of ring)



6. Install the inlet valve and connect the hose to toilet. Discharge the water for 3-5mins before connecting the hose to toilet so as to ensure the hose would be clogged by dirty.




WARNING

- The fittings are tested well before EXW. Do not dismantle them yourself.
- Do not replace the fittings and hose we supply.
- The manual base on the last product. We reserve the right to adjust the contents without further notice.


ATTN:

The product is with super siphonic jet flushing system. There would be splash and big noise if the water pressure is over 3KGS. Decrease water pressure by adjusting the valve to make flushing in a right way.



CAUTION

- Please close the valve during power cut.
- There would be splash and big noise if the water pressure is over 3KGS.
- Ensure install the product with the pipe and fittings which is combined in the packing or else the toilet would be leaking.




Using test

First time to open inlet valve and plug in power

After open the inlet valve and plug in power, if the night light and water temp. light flash, that means the water is entering into the heating tank. While the lights stop flashing in 30s that means the tank is filled up and please follow steps as below.


1.Sensor area

The area signed on image is for sensor. The main functions can be rooted only while the sensor sensing that people is seating on the cover bowl. (Except for Child Mode) Hearing beep sounds once means that people is sensed and the main functions is on standby already. The beep will sound once again while people leaving the seat.



2.Basin function test

Touch the sensor area until the beep sounds. Press the Rear & Bidet button to root the functions.



3.Drying function test

Touch the sensor area until the beep sounds. Press the Drying button to root it.



Problem & Solution

Problem clearing

PROBLEM	CHECKING	SOLUTION
Can not root	Power cut or no plug in power	Ensure plug in power
		Pull out the plug & plug in again
No water in flushing or not in smooth flushing	Water cut or inlet valve closed	Check the valve and open it
	The inlet filter is clogged	Clean the filter
Leaking	The nozzle is clogged by scale	Clean the nozzle by toothbrush
	Inlet valve is fully tightened	Tighten inlet valve and hose
Cool water & cool cover	The temp. adjusted to home temp.	Adjust the temp. again

Problem warning

PROBLEM	WARNING
Empty water	Night light & water temp. light flash together
Wrong with water temp. sensor	Water temp. light is off
Wrong with seat temp. sensor	Seat temp. light is off

☐ Routine maintenance

Surface cleaning

- ## Battery replacing

-


Nozzle cleaning

-

Inlet filter cleaning

-
- Diagram showing the connection of the pump to the main line. The pump is connected to the main line via a hose and a coupling.

Not used in long time

- 



pull cover up carefully

Loosen

drain off water

■ Specification

Name			Smart Toilet					
Voltage			AC220V 50/60Hz			Rated power		
						1430w (Inlet Temp 15°C±2°C, 0.2MPa)		
Washing Device	Heating Tank		0.3 L			Drying	Speed	≥4m/s
	Inlet Water Temp.		1°C~30°C				Temp.	4 Levels (home temp~55°C)
	Inlet Water Pressure		0.15~0.75 Mpa				Drying Power	250w
	Water Temp.		Adjustable Range: 30°C~40°C				Safety Device	Double metal sheet switch& Temp fuse
							Surface Temp.	4 Levels (home temp~40 °C)
	Water Output	Rear	0.35~1.2 L/min (0.2MPa)			Seat Temp	Heating Power	45w
		Bidet						
	Position	Rear	50~90 mm				Safety Device	Temp controller & Temp fuse
		Bidet						
	Power Rate		1600w				Structure	Soft close
Safety Device		Flow sensor, Temp sensor, Temp Switch, Temp Fuse			Safety Device	Leakage protection & Seating sensor		
				Length of wire		1.5m		

[illegible]
